



ATEQ F28+ Quick Start Guide






Table of contents

Safety advisory / Warranty

| | |
|---|---|
| Good practices and safety instructions..... | 4 |
| Air quality requirements..... | 5 |

Preamble

| | |
|--|---|
| ATEQ F28+, a universal leak meter..... | 6 |
| Leak test..... | 7 |
| Principle of a cycle..... | 8 |

Your ATEQ F28+

| | |
|--|----|
| Front panel..... | 9 |
| Connectors on the back panel (with all options)..... | 10 |
| Power supply connectors..... | 11 |
| Digital links..... | 12 |
| Digital inputs/outputs..... | 16 |
| Pneumatic connectors..... | 20 |
| Pneumatics configuration..... | 23 |

User interface (remote control)

| | |
|---------------|----|
| Overview..... | 28 |
| Keys..... | 29 |
| Display..... | 30 |

Starting up

| | |
|--|----|
| Power up..... | 32 |
| Preparing a program..... | 32 |
| Modifying a parameter..... | 33 |
| Selecting a program..... | 34 |
| Starting and stopping current cycle..... | 34 |

User adjustments

| | |
|---------------------------|----|
| Options of the menus..... | 35 |
|---------------------------|----|




Specifications


| | |
|----------------------|----|
| Characteristics..... | 41 |
|----------------------|----|




ATEQ Manufacturer Plants - Measurement Solution, Global Leader.

3/42

|  |  |  |
|--|---|---|
| ATEQ 15, rue des Dames, Z.I. 78340 LES CLAYES-SOUS-BOIS FRANCE | info@ateq.com ateq.com | T.: +33 1 30 80 1020 F.: +33 1 30 54 1100 |
| ATEQ K.K. 3 - 41 ATEQ Building, Ikehata Chiryu-city, Aichi-pref JAPAN | info@ateq.co.jp ateq.co.jp | T.: +81 566-84-4670 F.: +81 566-84-4680 |
| ATEQ China 98 Jian Peng Lu Shanghai CHINA | shanghai@ateq.com.cn ateq.com.cn | T.: +86 21 6763 9508 F.: +86 21 6763 9528 |
| ATEQ SYSTEMS ANALYSIS TAIWAN CO., LTD. NO. 3, LAN 223, San Jia Dong Street 40642, TAICHUNG TAIWAN | ateqtaiwan@ateq.com.tw ateq.com.tw | T.: +886 4 2437 5278 F.: +886 4 2437 3675 |
| ATEQ CORP. 35980 Industrial Road Suite L Livonia MI 48150 UNITED STATES | leaktest@atequsa.com atequsa.com | T.: +1 734-838-3100 F.: +1 734-838-0644 |

 We continuously work on improving our products. This is why information contained in this manual, the device and the technical specifications may be modified without prior notification.

 Pictures and figures in this manual are non-contractual.





Safety advisory / Warranty

GOOD PRACTICES AND SAFETY INSTRUCTIONS

Safety recommendations



If the device is supplied with 100 / 240 V AC, it is mandatory to connect it to the ground with a good link to the ground, to protect against electric hazard or electrocution.



It is dangerous to change the status of the outputs.
They can control power actuators or other equipment (mechanical, pneumatic, hydraulic, electrical or other) which can cause serious personal injury and damage to surrounding material.



For safety and quality measurement reasons, it is important, before powering on the device, to ensure that it is air supplied with a minimum operating pressure (0.6 MPa (87 PSI) \pm 15%).

Recommendations for the test environment

Keep the test area as clean as possible.

Recommendations for operators

ATEQ recommends that the operators who use the devices have training and a level of qualification that correspond to the job to perform.

General recommendations

- Read the user manual before using the device.
- All electrical connections to the device must be equipped with safety systems (fuses, circuit breakers, etc.) adapted to the needs and in accordance with the applicable standards and rules.
- To avoid electromagnetic interference, electrical connections to the device must be shorter than 2 meters.
- Power supply plug must be grounded.
- Disconnect the device from the electrical outlet before performing any maintenance work.
- Shut off the compressed air supply when working on the pneumatic assembly.
- Do not open a connected device.
- Avoid splashing water on the device.

ATEQ is at your disposal for any information concerning the use of the device under maximum safety conditions.

We draw your attention to the fact that ATEQ cannot be held responsible for any accident related to a misuse of the measuring instrument, the workstation or non-compliance of the installation with safety rules.

In addition, ATEQ declines any responsibility for the calibration or the fitting of their instruments that is not done by ATEQ.

ATEQ also declines any responsibility for any modification (program, mechanical or electrical) of the device done without their written consent.






AIR QUALITY REQUIREMENTS

The air supplied into the device must be clean and dry. Even though the device is provided with a filter, the presence of dust, oil or impurities may cause malfunction.

5/42

Air quality requirements according to ISO standard 8573

-  The air must be clean and dry.
-  The presence of impurities, oil or humidity in the air may cause deterioration which will not be covered by the warranty.
-  When the instrument is working in vacuum conditions, impurities must be prevented from being drawn into its internal components.
For this purpose we strongly recommend that a suitable airtight filter is installed between the part under test and the instrument.

ATEQ recommends the following characteristics for the air supplied into the device.

| Air characteristics | | ISO standard 8573 class |
|------------------------------|---|-------------------------|
| Grain size and concentration | 0.1 μm and 0.1 mg/m ³ | Class 1 |
| Dew point under pressure | - 40°C dew | Class 2 |
| Maximum concentration of oil | 0.01 mg/m ³ | Class 1 |

Recommended additional equipment

ATEQ recommends the installation of this additional equipment:

- Air dryer to provide dry air at less than - 40°C dew point
- 25 micron and 1/100 micron double filter.





Preamble

ATEQ F28+, A UNIVERSAL LEAK METER

ATEQ F28+ is a universal leak meter that measures flow rates through parts to test.




ATEQ F28+ can memorise 128 different test programs.



LEAK TEST

Direct measurement principle

7/42




The part under test **3** and the reference part **5** are filled to an identical pressure. A differential sensor **4** measures the pressure variation between the part under test **3** and the reference part **5**. In some applications, the reference part can be replaced by a cap.

- 1 Device
- 2 Pressure sensor
- 3 Part under test
- 4 Differential pressure sensor
- 5 Reference part

Desensitized test

This mode is used for the measurement of large leaks, when the reject level required is above the full scale of the differential sensor.



The test pressure is applied to the input of the test part **3**.

The measurement is performed by the pressure sensor **2**.

- 1 Device
- 2 Pressure sensor
- 3 Part under test
- 4 Cap on the reference connector


Other types of test are available in option (Burst test, Volume, Operator...).





PRINCIPLE OF A CYCLE

The measurement cycle is made of 4 main phases: fill, stabilization, test, dumping.



- 0 Waiting phase
- 1 Fill phase
- 2 Stabilization phase
- 3 Test
- 4 Dumping







Your ATEQ F28+

9/42

FRONT PANEL

The user interface is located on the front panel.





| Ref | Name | Description |
|-----|------|---|
| 1 | J7 | 24 V DV power supply |
| 2 | - | Power on indicator |
| 3 | J9 | Program selection extension connector |
| 4 | - | Not used |
| 5 | - | 0.6 MPa (87 PSI) air valve supply |
| 6 | - | Regulated air pressure input 1 (option) |
| 7 | - | Regulated air pressure input 2 (option) |
| 8 | J5 | Fieldbus connector (option) |
| 9 | J6 | Fieldbus connector (option) |
| 10 | ATEQ | Part number / Serial number |
| 11 | J2 | USB connector to PC |
| 12 | J3 | USB connector to remote control |
| 13 | J10 | Outputs code board connector (digital inputs/outputs) |
| 14 | J8 | Relay board connector (digital inputs/outputs) |
| 15 | - | Ground |
| 16 | JX | Profibus (option) |
| 17 | J12 | RS232 connector |



CONNECTORS ON THE BACK PANEL (WITH ALL OPTIONS)

10/42



| Ref | Name | Description |
|-----|------|--|
| 1 | R | Reference part connector |
| 2 | P2 | Not used |
| 3 | - | Exhaust output |
| 4 | V1 | Differential sealed part connector (option) |
| 5 | - | Quick connector |
| 6 | V | Calibration check by volume variation connector (option) |
| 7 | V2 | Differential sealed part connector (option) |
| 8 | A | Pneumatic output or A automatic connector (option) |
| 9 | T | Test part connector |
| 10 | P1 | Pressurization output |




POWER SUPPLY CONNECTORS

24 V DC connector (J7)

The device can be connected to a 24 V DC - 2 A power supply through a M12 4 pins type connector.

11/42



| Pin number | Signal |
|------------|---------------|
| 1 | + 24 V DC |
| 2 | Not connected |
| 3 | Ground: 0 V |
| 4 | Not connected |




DIGITAL LINKS

12/42

PC USB connectors


USB connectors can be used for connecting miscellaneous compatible USB devices.
The USB connectors are located under the rubber cover **1** (see figure).




- 1** Rubber cover
- 2** USB connector to PC (J2)
- 3** USB connector to remote control (J3)

 Do not connect two USB devices at the same time.

 Do not use a cable longer than 2 m.


 Push the rubber cover **1** slightly forward for an easy access to USB connectors **2** and **3**.

 Only use this connection for temporary communication. Connection to a PC cannot be used permanently because the communication can be disconnected by the PC.

Printer RS232 connector / Modbus (option)

RS232 - SubD 9 pins male connector (printer) (J12)

RS232 for printer, barcode reader, PC connection.



| Pin number | Signal |
|------------|---------------------|
| 1 | Not used |
| 2 | RXD data input |
| 3 | TXD data input |
| 4 | Not used |
| 5 | Ground |
| 6 | Not used |
| 7 | RTS request to send |
| 8 | CTS clear to send |
| 9 | Not used |




Profibus connector (JX) (option)

Profibus - SubD 9 pins female connector

Profibus: SubD 9 pins female connector


13/42



| Pin number | Signal |
|------------|------------------------------------|
| 1 | PE (ground) |
| 2 | Not used |
| 3 | Data line A |
| 4 | CNTR - A (repeater control signal) |
| 5 | DGND (logic ground) |
| 6 | VP (supply) |
| 7 | Not used |
| 8 | Data line B |
| 9 | Not used |

Profinet connector (J5 + J6)

M12 D coded type connector - 4 pins female connector (J5 + J6)




| Pin number | Signal |
|------------|---------------------------------|
| 1 | Ethernet Tx + (Transmit Data +) |
| 2 | Ethernet Rx + (Receive Data +) |
| 3 | Ethernet Tx - (Transmit Data -) |
| 4 | Ethernet Rx - (Receive Data -) |



Devicenet connectors (J5) (J6) (option)

M12 type connector - 5 pins male connector (J5) (Devicenet input)


For connection to others ATEQ devices.



| Pin number | Signal |
|------------|--------|
| 1 | Drain |
| 2 | V+ |
| 3 | V- |
| 4 | CAN_H |
| 5 | CAN_L |

M12 type connector - 5 pins female connector (J6) (Devicenet output)

For connection to others ATEQ devices.




| Pin number | Signal |
|------------|--------|
| 1 | Drain |
| 2 | V+ |
| 3 | V- |
| 4 | CAN_H |
| 5 | CAN_L |



Ethernet connector (J5 + J6) (option)

Standard connection Ethernet TCP / IP protocol.



One of these network protocols is available:

- Ethernet IP
- Profinet
- Ethercat.

The 24V DC power supply for the digital inputs can be provided by 2 means:

- Inputs default mode is PNP. NPN mode is available on request.

Characteristics

-
- J8**
1 (Output)
200mA
- 16** ▲ 0V
-O5
-O4
-O3
-O2
-O1
▲ C
-I7
-I6
-I6
-I4
-I3
▲ 24V
-I2
▲ 24V
-I1
- 1**

| Pin number | Inputs / outputs | Description |
|------------|------------------|--|
| 1 | Input 1 | RESET |
| 2 | + 24 V DC | Common |
| 3 | Input 2 | START |
| 4 | + 24 V DC | Common |
| 5 | Input 3 | Program selection |
| 6 | Input 4 | Program selection |
| 7 | Input 5 | Program selection |
| 8 | Input 6 | Program selection |
| 9 | Input 7 | Program selection (programmable input) |
| 10 | Output | Common floating output |
| 11 | Output | Pass part |
| 12 | Output | Test fail part |
| 13 | Output | Reference fail part |



| Pin number | Inputs / outputs | Description |
|------------|------------------|--------------|
| 14 | Output | Warning |
| 15 | Output | End of cycle |
| 16 | 0 V | Ground |


Program selection extension connector (J9)

The J9 connector is an extension of the J8 connector that enables the selection of 128 programs.

Characteristics

– Inputs

- Activation: + 24 V DC.



| Pin number | Inputs/outputs | Description |
|------------|----------------|---|
| 18 | Input 8 | Program selection from 33 to 64 (programmable input) |
| 19 | Input 9 | Program selection from 65 to 128 (programmable input) |



Program selection (J8 and J9)

The connectors J8 and J9 enable you to select a program from digital inputs.
Combinations of connector pins to activate for program selection


| Program number | J8 | | | | J9 | | |
|----------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | Pin 5 (input 3) | Pin 6 (input 4) | Pin 7 (input 5) | Pin 8 (input 6) | Pin 9 (input 7) | Pin 1 (input 8) | Pin 2 (input 9) |
| 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 2 | 1 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3 | 0 | 1 | 0 | 0 | 0 | 0 | 0 |
| 4 | 1 | 1 | 0 | 0 | 0 | 0 | 0 |
| 5 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| 6 | 1 | 0 | 1 | 0 | 0 | 0 | 0 |
| 7 | 0 | 1 | 1 | 0 | 0 | 0 | 0 |
| 8 | 1 | 1 | 1 | 0 | 0 | 0 | 0 |
| 9 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| 10 | 1 | 0 | 0 | 1 | 0 | 0 | 0 |
| 11 | 0 | 1 | 0 | 1 | 0 | 0 | 0 |
| 12 | 1 | 1 | 0 | 1 | 0 | 0 | 0 |
| 13 | 0 | 0 | 1 | 1 | 0 | 0 | 0 |
| 14 | 1 | 0 | 1 | 1 | 0 | 0 | 0 |
| 15 | 0 | 1 | 1 | 1 | 0 | 0 | 0 |
| 16 | 1 | 1 | 1 | 1 | 0 | 0 | 0 |
| 17 to 32 | X* | X | X | X | 1 | X | X |
| 33 to 64 | X | X | X | X | X | 1 | X |
| 65 to 128 | X | X | X | X | X | X | 1 |

 * X is equal to 0 or 1 in function of the program number.

Valve code board connector (J10) (option)

Characteristics

- Outputs:
 - 24 V DC - 100 mA max per output.
- Inputs:
 - Activation: + 24 V DC.



| Pin number | Inputs / outputs | Description |
|------------|------------------|--------------------------|
| 1 | + 24 V DC | Common (outputs 1, 2,3) |
| 2 | Output 1 | Open collector |
| 3 | Output 2 | Open collector |
| 4 | Output 3 | Open collector |
| 5 | + 24 V DC | Common (outputs 4, 5, 6) |
| 6 | Output 4 | Open collector |
| 7 | Output 5 | Open collector |
| 8 | Output 6 | Open collector |
| 9 | Input 1 | Programmable input |
| 10 | Input 2 | Programmable input |
| 11 | Input 3 | Programmable input |
| 12 | Input 4 | Programmable input |
| 13 | Input 5 | Programmable input |
| 14 | 0 V | Ground |
| 15 | Input 6 | Programmable input |
| 16 | 0 V | Ground |



PNEUMATIC CONNECTORS

Pneumatic connectors used to connect the part under test are located on the back panel of the device, except for pneumatic supply.

20/42

Pneumatic supply (on front panel)




The pneumatic supply has to meet specific requirements recommended by ATEQ. Refer to Good practices and safety instructions section.

The air is supplied via the 0.6 MPa (87 PSI) valve air supply input (1).

Two other pneumatic inputs (2) and (3) are available for an external regulated air supply (option).


0.6 MPa (87 PSI) \pm 15% valve air supply input (1)



PILOT PRESS

Regulated air pressure input 1 (option) (2)

TEST
PRESS 1



External regulation: test pressure 1:


— max = sensor full scale

Internal electronic regulation:

— max = regulator full scale

Regulated air pressure input 2 (option) (3)

TEST
PRESS 2



External regulation: test pressure 2:

— max = sensor full scale

Internal electronic regulation:


— max = regulator full scale





Test and reference outputs

The outputs enables parts to be connected (test and reference)



- 1 Test connector
- 2 Reference connector
- 3 Not used
- 4 Exhaust output
- 5 Pressurization output


Metallic fitting available for test (1) and reference (2) connectors:

- 2.7/4 mm
- 3/5 mm
- 4/6 mm
- 6/8 mm

21/42

Quick connector (option)


Use this function to check the calibration.



|| As this connector is part of the measurement circuit, all its connections must be air tight.

Calibration check by volume variation connector (option) (V)


External volume (closed tube) connection.





Differential sealed part connectors (option) (V1 and V2)

External volume (closed tube) connection.



Pneumatic output 0.6 MPa (87 PSI) (option)

Pneumatic output or **A** automatic connector option.






PNEUMATICS CONFIGURATION

23/42

Direct mode - Test with external regulator

From vacuum until 2 MPa (290 PSI)




Connections

| Connection | Option / description |
|-----------------|--|
| Air supply to 1 | Connection of the air supply to the valve air supply input |
| 3 to 2 | Connection of an external regulator to the regulated air pressure input 1 |
| 5 to 4 | Connection of an external regulator to the regulated air pressure input 2 (option) |
| 7 to 6 | Connection of the reference output to the reference part |
| 10 to 11 | Connection of the test output to the part under test |
| 8 | Connection to additional volume (sealed part option) |
| 9 | Connection to pneumatic coupler |



Direct mode - Test with internal regulator

From vacuum until 0.5 MPa (72.5 PSI)



Connections


| Connection | Option / description |
|--------------------|--|
| Air supply to 1 | Connection of the air supply to the valve air supply input |
| Vacuum supply to 2 | Connection of the vacuum supply to the regulated air pressure input 2 (option) |
| 4 to 3 | Connection of the reference output to the reference part |
| 6 to 7 | Connection of the test output to the part under test |
| 5 | Connection to pneumatic coupler |



Direct mode - Test with internal regulator

From 0.6 MPa (87 PSI) until 2 MPa (290 PSI)

25/42



Connections


| Connection | Option / description |
|--------------------|---|
| Air supply to 1 | Connection of the air supply to the valve air supply input |
| Air supply to 2 | Connection of the air supply to the internal pressure regulator |
| Vacuum supply to 3 | Connection of the air supply to the internal vacuum regulator |
| 5 to 4 | Connection of the reference output to the reference part |
| 7 to 8 | Connection of the test output to the part under test |
| 6 | Connection to pneumatic coupler |



Direct mode - Option test check by pressure drop

Maximum pressure: 0.4 MPa (58 PSI)

26/42



Connections

| Connection | Option / description |
|-----------------|---|
| Air supply to 1 | Connection of the air supply to the valve air supply input |
| 3 to 2 | Connection of the reference output to the reference part |
| 7 to 8 | Connection of the test output to the part under test |
| 4 to 5 | Connection of the external volume output to an additional volume, if necessary (option) |
| 6 | Connection to pneumatic coupler |





Direct mode - Sealed part differential volume test

Maximum pressure: 1 MPa (145 PSI)

This configuration can be used for test of small test part volumes.

27/42

 Protect volumes and pipes from air blowing and temperature variations.



Connections

| Connection | Option / description |
|-----------------|---|
| Air supply to 1 | Connection of the air supply to the valve air supply input |
| 3 to 2 | Connection of the reference output to the reference part |
| 9 to 10 | Connection of the test output to the part under test |
| 4 to 5 | Connection of the volume output V1 to an additional volume, if necessary (option) |
| 7 to 6 | Connection of the volume output V2 to an additional volume, if necessary (option) |
| 6 | Connection to pneumatic coupler |





User interface (remote control)

The ATEQ F28+ can be set up and supervised using a remote control (option) connected to the USB connector.



The ATEQ F28+ can also be set up and supervised on a PC with a specific software (Winat eq 300).

OVERVIEW



- 1 Display
- 2 Cycle keys
- 3 Navigation keys





KEYS

Cycle keys





29/42

The cycle keys are used to start and to stop a measurement cycle.

| Key | Name | Function |
|---|--------------|---|
|  | Start | On the Program screen, starts a measurement cycle and opens the Measurement cycle screen. |
|  | Reset | Stops the measurement cycle in progress and returns to the Program screen. |


Navigation keys

The navigation keys are used to select menus/options and change parameter values.

| Key | Name | Function |
|---|-----------------|---|
|  | Up key | Scrolls up or increases numerical values. |
|  | Down key | Scrolls down or decreases numerical values. |
|  | OK | Returns to the MAIN MENU screen or opens menus and options, validates parameters. |
|  | Esc | Returns to previous screen (until the Program screen), escapes without modifying parameters. |

Smart key

Smart key is a programmable key that provides direct access to a function selected by the user.

| Key | Name | Function |
|---|------------------|---|
|  | Smart key | Starts a measurement cycle (default, programmable). |

This key is programmable through the **MAIN MENU** screen:

MAIN MENU > CONFIGURATION > MISCELLANEOUS > SMART KEY




DISPLAY

The device uses three main screens.

The Program screen

Use the **Program** screen to select a test program.




- 1 Current program name (here **NAME**)
- 2 Current program number (here **001**)
- 3 Test type (here **LEAK TEST**)

i | Access at startup of the device or by pressing several times **Esc** .

The Measurement cycle screen

The **Measurement cycle** screen displays the different values of the current test (or last one).



- 1 Test pressure measurement
- 2 Test result or step phase
- 3 Test reject value
- 4 Vertical line test result
- 5 Remaining time of the current phase or ready status
- 6 Leak measurement
- 7 Measurement unit
- 8 Current program
- 9 Vertical line test result

i | A star (*) can be displayed after the measurement unit **7** when the standard conditions function is validated.
Refer to the Reference Manual..




The MAIN MENU screen

The **MAIN MENU** screen gives access to different sections for managing the device and the test parameters.

31/42

 Access: from the **Program** screen, press .



| Option | Description |
|----------------------|---|
| SPE CYCLE | Specific procedures necessary to ensure the proper operation of measurement cycles (for example, adjustment of a pressure regulator). |
| PARAMETERS | Parameters of the test programs. |
| CONFIGURATION | General configuration of the device. |
| SERVICE | Maintenance of the device. |
| RESULTS | Test results, backup and display options. |
| USB | USB connection functions (backup, restore). |



Starting up

POWER UP


1. Make sure that all the necessary connections are in place.

Electrical: such as power supply, inputs/outputs

Pneumatic: including line pressure supply

2. Power up your device.

When power-up is completed, the **Program** screen is displayed with last program used on screen.




PREPARING A PROGRAM

Use this procedure to configure a new test program.


On the **MAIN MENU** screen:

ACCESSING THE PARAMETERS

1. Select **PARAMETERS** using the up/down keys and press **OK**.



The program list is displayed.




SELECTING A PROGRAM NUMBER

2. Select the program to configure and press **OK**.

A list of the available measurement types is displayed:

- **LEAK TEST** type
- **BLOCKAGE** type
- **DESENSITIZED TEST** type
- **OPERATOR** type
- **BURST TEST** type (option)
- **VOLUME** type (option)





CONFIGURING THE ASSOCIATED MEASUREMENTS

3. Select a measurement type and press **OK**.

The parameters of the selected measurement type are displayed.

4. Define the measurement cycle parameters.

See: Modifying a parameter.

| PARAM / Pr 001 | |
|--------------------|-------|
| ▶ TYPE : LEAK TEST | |
| COUPL. A : | 0.0 s |
| FILL TIME : | 2.0 s |
| STAB TIME : | 2.0 s |
| TEST TIME : | 2.0 s |
| DUMP TIME : | 1.0 s |
| Press. UNIT : | bar |
| Max FILL : | 5.00 |

33/42

MODIFYING A PARAMETER

Use this procedure to complete the test program setup.

On the **MAIN MENU** screen of the program (see: Preparing a program):

1. Press up/down to select the parameter to modify, and press **OK**.

| PARAM / Pr 001 | |
|------------------|-------|
| TYPE : LEAK TEST | |
| COUPL. A : | 0.0 s |
| FILL TIME : | 2.0 s |
| STAB TIME : | 2.0 s |
| ▶ TEST TIME : | 2.0 s |
| DUMP TIME : | 1.0 s |
| Press. UNIT : | bar |
| Max FILL : | 5.00 |

An arrow is displayed on the right of the parameter being modified.

| PARAM / Pr 001 | |
|------------------|---------|
| TYPE : LEAK TEST | |
| COUPL. A : | 0.0 s |
| FILL TIME : | 2.0 s |
| STAB TIME : | 2.0 s |
| TEST TIME : | 2.0 s ◀ |
| DUMP TIME : | 1.0 s |
| Press. UNIT : | bar |
| Max FILL : | 5.00 |

2. Use the up/down keys to modify the parameter value, and press **OK** to validate.

The arrow returns to the left of the modified parameter.

| PARAM / Pr 001 | |
|------------------|-------|
| TYPE : LEAK TEST | |
| COUPL. A : | 0.0 s |
| FILL TIME : | 2.0 s |
| STAB TIME : | 2.0 s |
| ▶ TEST TIME : | 1.0 s |
| DUMP TIME : | 1.0 s |
| Press. UNIT : | bar |
| Max FILL : | 5.00 |

3. Repeat these steps until all parameters are set.
4. To return to the **MAIN MENU** screen, press **Esc** as many times as necessary.





SELECTING A PROGRAM

If necessary, you can select another program.

1. Press up/down  .



STARTING AND STOPPING CURRENT CYCLE

Use the front panel keys to start/stop a measurement cycle.
With the desired program displayed on the **Program** screen:

STARTING A MEASUREMENT CYCLE

1. Press Start .

The cycle phases of the program are successively displayed:


FILL

STABILISATION

TEST


DUMP

At the end of the cycle, the results are displayed and **READY** appears at the bottom right of the screen.



During the measurement cycle, you may press **OK** to access the **MAIN MENU** screen and set parameters for a next measurement cycle.

STOPPING A CYCLE

2. Press Reset  to immediately stop the current measurement cycle and return to the **Program** screen.




User adjustments

OPTIONS OF THE MENU

Different menus are accessible on the **MAIN MENU** screen.

SPE CYCLE menu

Use this menu to carry out specific procedures necessary to ensure the proper operation of specific measurement cycles (for example, adjustment of pressure regulator).





| Label | Special cycle | Description of the cycle |
|-------------------|----------------------|--|
| none | None | No special cycle selected |
| Regulator adjust. | Regulator adjustment | Adjustment of regulator in front panel |
| Inf Fill | Infinite fill | Pressurize the part with a infinite fill time |
| Piezo auto zero | Piezo auto zero | Auto zero cycle on the piezo sensor |
| AUTO VOL | Automatic volume | Volume calculation for automatic program selection |

Other cycles are available only when specific functions are used:

- **Custom Unit Learn:** see: Customized unit learn
- **Custom Unit Check:** see Customized unit check

TO START SPECIAL CYCLES...

1. On the **SPECIAL CYCLE MENU** screen, select a cycle, and press **OK** to validate.
2. Press **Start**  to start the cycle.
3. To stop the current cycle press **Reset** .



PARAMETERS menu

Use this menu to configure the measurement cycle associated to each test program.

| PARAM / Pr 001 | | |
|----------------|-----------|--|
| ▶ TYPE : | LEAK TEST | |
| COUPL. A : | 0.0 s | |
| FILL TIME : | 2.0 s | |
| STAB TIME : | 2.0 s | |
| TEST TIME : | 2.0 s | |
| DUMP TIME : | 1.0 s | |
| Press. UNIT : | bar | |
| Max FILL : | 5.00 | |

Default parameters of the **LEAK** type tests

| Label | Parameter | Description |
|-----------------------------|-----------------------|--|
| COUPL. A or COUPL. B | Coupling time | Required times when instrument manage automatic jigs |
| FILL TIME | Fill time | Time to pressurise the part under test |
| STAB TIME | Stabilization time | Time to stabilise the pressure on the test and reference parts |
| TEST TIME | Test time | Time for leak measurement |
| DUMP TIME | Dump time | Time to vent the part to atmosphere |
| Press. UNIT | Pressure units | Pressure unit (bar, mbar, PSI, Pa, kPa, MPa) |
| Max FILL | Maximum fill pressure | Maximum level of the fill pressure |
| Min FILL | Minimum fill pressure | Minimum level of the fill pressure |
| LeakUnit | Reject unit | Measurement units |
| Test FAIL | Test fail | Upper leak rate limit for the test part.. Above this limit, the part is considered as defective. |
| Ref. FAIL | Reference fail | Reference part reject level |
| FUNCTIONS | Functions | Access to additional functions |

Additional functions

| Label | Function | Description |
|------------------------------|-------------------------|---|
| 24V OUTPUTS | Auxiliaries output 24 V | Available outputs for external automatism |
| ABSOLUTE | Absolute | Display the absolute value of the results |
| ATF | ATF time | Absorb the important leak variations at the defined time |
| ATR0/ATR1 / ATR2/ATR3 | ATR 0 - 3 | Specific filters on leak measurement |
| AUTO CONNECT | Automatic connector | Function to manage automatic jigs |
| BUZZER | Buzzer | Buzzer activation configuration |
| CODE READER | Bar code reader | Bar code configuration |
| CUT OFF | Cut off | All the measurements that are lower than the configured rate have the value 0 |
| DISP. OPT. | Display option | Allows to display two lines for measurement with a selected information |
| DISPLAY MODE | Display Mode | Flow measurement resolution |



| Label | Function | Description |
|-----------------------------------|-------------------------|---|
| DUMP OFF | Dump off | Disable the dump phase in the program parameters |
| END OF CYCLE | End of cycle | Several automatism case depending on fail part management |
| EXT. DUMP | External dump | The test part is vented to atmosphere through an external valve |
| FILL MODE | Fill types | Special filling methods |
| FILTER | Filtering | Stabilize the measurement values |
| FLOW LEVEL | Flow level | Add a minimum fail parameter |
| MINI-VALVE | Mini valve | Access to highest time resolution (fast test) and auto zero time |
| NAME | Name | Program customization |
| NO NEGATIVE | No Negative | Replace negative value per 0 |
| N TESTS | N TESTS | Repeats the test when the results get close to the reject level |
| PEAK HOLD | Peak hold | Give as result, the highest measurement value during the test time |
| PR:SEQUENCE | Sequencing | Allowed program automatic sequencing |
| PRE-FILL | Pre-fill types | Special filling methods |
| PRESSURE DROP | Pressure drop | Pressure drop mode function in the Desensitized mode |
| REF. VOLUME | Reference volume | Adjust the reference volume value with flow units only |
| REWORK LIMIT | Rework limits | Additional levels for specific reworkable parts |
| Sd Part SD PART 2 SD PART 3 | Sealed part | Several optional ways to test sealed parts |
| SEALED DIFF | Sealed differential | Allows testing small parts volume difference between test and reference volumes |
| SIGN | Sign | Return opposite result |
| STAMPING | Stamp | Pneumatic or electric output to identify the part |
| STD CONDITIONS | Standard conditions | Standard conditions correction with parameters |
| SYNC. TEST | Synchro test | A programmable input allows to pass from Stabilization to Test phase |
| T+R TEST | Test and reference test | Display which part has failed during a test with two parts |
| TEMP.CORR. 1 | Temperature correction | Software temperature test part correction |
| TEST CHECK | Calibration check | Calibration check by adding a volume at the end of test time |
| UNITS | Units | Access to International System or American or Custom Units |
| VALVE CODES | Valve codes | Available outputs for external automatism |




Others functions are available depending on software version.







CONFIGURATION menu

Use this menu to configure your ATEQ device.




| Label | Function | Description |
|--------------------------|---------------|--|
| LANGUAGE | Language | Selection of the language displayed on the screen |
| PNEUMATIC | Pneumatics | Configuration of the pneumatics functions of the device |
| > AUTO VOL | - | Configuration of volume calculation for automatic program selection (option) |
| > ELEC. REG. | - | Activation of the electronic regulator |
| > REGUL. CTRL. | - | Configuration of the electronic regulator (external or auto) (option) |
| > PERM. REG. | - | The electronic regulator is active every time |
| > PIEZO AUTO AZ | - | Configuration the frequency of the auto zero |
| > AZ SHORT | - | Deactivation of the linearization of the regulator during the auto zero process (option) |
| > Press. UNIT | - | Pressure unit by default for the new programs |
| > DUMP LEVEL | - | Configuration of the minimum dump level pressure |
| > LINE P. MIN | - | Minimum level for checking line pressure (option) |
| > BLOW MODE | - | Blowing mode when test cycle is not running (option) |
| > EXT. DUMP | - | Configuration of the external dump (option) |
| > DUMP OFF | - | Remove dump time parameter on the selected program that becomes 0 second |
| AUTOMATISM | Automatism | Configuration of the different communications between the device and its environment |
| > RS232 | - | Configuration of the communication type on the RS232 port |
| > USB | - | Sending result frames to a PC |
| > Date & Time | - | Setup of the built-in clock |
| > OUTPUTS CONFIG. | - | Configuration of the programmable outputs |
| > INPUTS CONFIG. | - | Configuration of the programmable inputs |
| > CODE READER | - | Bar code reader configuration |
| SECURITY | Security | Security functions |
| > ACCESS | - | Parameters access mode (key or password) |
| > START OFF | - | Deactivation of the Start  on the instrument front panel. Programs can only be started from the instrument relay board or by the fieldbus. |
| MISCELLANEOUS | Miscellaneous | |
| > SMART KEY | - | Configuration of the assigned function to the Smart key  |



SERVICE menu

Use this menu to do the maintenance of your device (status check, internal tests...).




39/42

| Label | Function | Description |
|-----------------------|------------------------|---|
| CAN STATUS | Internal network state | State of the internal network of the device |
| I/O STATE | Inputs/outputs state | State of the inputs/outputs |
| VALVE COUNTER | Valves wear function | Approximate state of the valves wear |
| DEVICE INFOS | Device information | Information about the device, program version, built in components etc. |
| SERVICE CYCLES | Special service cycles | Allows to display more special cycles to carry out device internal tests (see Service special cycles) |
| RESET PARA | Parameters reset | Reset to factory configuration |

RESULTS menu

In this section, manage measurements results.




| Label | Function | Description |
|----------------------|--------------------|---|
| SAVE ON | - | Define memory location (internal or external USB stick) |
| LAST RESULTS | Results display | Last 1500 results carried out by the device |
| TRANSFER USB | Results transfer | Transfer all results to USB stick on CSV file |
| Results Reset | Results erasing | The results are lost after the reset |
| STATISTICS | Results statistics | Statistics for each program |



USB menu

This section describes save and restore parameters on an external USB device.



| Label | Description |
|--------------------|--|
| Save parameters | Save parameters on an external USB memory device for restoring later |
| Restore parameters | Restore parameters from an external USB memory device |



Specifications

41/42

CHARACTERISTICS

Technical characteristics of the device.

Main characteristics

| Characteristics | Values |
|------------------------------------|--|
| Dimensions: height x width x depth | 157 x 299 x 136 mm (6.18 x 11.77 x 5.35") |
| Weight | About 3.5 kg (7.70 lb) |
| Electrical power supply | 24 V DC - 2A |
| Overvoltage category | II |
| Pressure range | Several ranges from vacuum to 2 MPa (290 PSI) |
| Leak measurement range | 3 FS: 50 / 500 / 5000 Pa |
| Protection | Device protection level IP2 |
| Operation temperature | +5 °C to + 45 °C (+ 41 °F to 113 °F) |
| Storage temperature | 0 °C to +60 °C (32 °F to 140 °F) |
| Operation altitude | Up to 2000 m (6500') |
| Relative humidity | 80 % at 31 °C (87 °F) and 50 % at 40 °C (104 °F) |

